# TWOWIN TW-T801S User Guide

Smarter World, Better Life

图为信息科技(深圳)有限公司

TWOWIN INFORMATION TECHNOLOGY Co. Ltd

# Contents

Document Revision Catalog ..... 1
Foreword ..... 2
Safety Warning and Precautions for Use ..... 3
Introduction ..... 5
Product Specification ..... 6
Processor and Core Module ..... 6
Interface Introduction ..... 7
Encoding and Decoding ..... 8
Power Supply ..... 8
Structure ..... 8
Environment ..... 8
Size ..... 9
Service and Support ..... 10
Technical Support ..... 10
Warranty ..... 10
Interface Description ..... 11
Front Interface ..... 11
WiFi antenna connection diagram ..... 11
Side Interface ..... 12
40 PIN Show Picture ..... 12
Back Interface ..... 14
Usage Introduction ..... 15
System Introduction ..... 15
Switch on and off ..... 15
Work Mode Switching ..... 16
WIFI Connection (if optional) ..... 17
1 Update source and software ..... 20
2 Set a fixed IP address with commands ..... 21
Basic Algorithm Framework Installation ..... 22
Pytorch Installation ..... 22
Torchvision Installation ..... 23
Yolo v4 environment setup ..... 24
TWOWIN Information Technology(ShenZhen)Co.,Ltd. Warranty Terms ..... 27

# Document Revision Catalog

## Document Version

Version 1.0

| Document Version Number | Revision Date | Revision Content |
|---|---|---|
| V1.0 | 2024/12/16 | Initial release |

# Foreword

Before using this manual, please carefully read the following usage license agreement. Only by agreeing to the following usage license agreement can you use the products introduced in this manual

## Copyright Notice

The copyright belongs to Twowin Technology Co., Ltd., and the final interpretation and modification rights of this document and this statement are reserved. Any textual description, document format, illustrations, photos, methods, processes, etc. appearing in this document, unless otherwise specified, shall be the property of Twowin Technology Co., Ltd for copyright or other related rights. Without the written consent of Twowin Technology Co., Ltd, no one is allowed to copy, excerpt, backup, modify, disseminate, translate into other languages, or use all or part of this manual for commercial purposes in any way or form.

## Technical Support and Information Feedback

If you encounter any problems while using our product, or if you believe that our product has certain functional defects, please visit our official website https://www.twowintech.com contact our customer service and we will solve your problems and provide feedback; If you need technical support guidance or have any valuable opinions, please contact us through our official website or phone.

## Notice

The products, services, or features you purchase shall be subject to the commercial contract and terms of Twowin Technology Co., Ltd. All or part of the products, services, or features described in this document may not be within your scope of purchase or use. Unless otherwise agreed in the contract, Twowin Technology Co., Ltd makes no express or implied representations or warranties regarding the content of this document

Due to product version upgrades or other reasons, the content of this document may be updated periodically. Unless otherwise agreed, this document is for use only and all statements, information, and recommendations in this document do not constitute any express or implied warranties.

Contact : Twowin Information Technology（Shenzhen）Co.,Ltd
Tel: 0755-82840481
Website: https://twowintech.com/
Email:oversea@Twowin.com
Address: Room 2512, Changhong Technology Building, No. 12, Keji South 12th Road, Nanshan District, Shenzhen

# Safety Warning and Precautions for Use

- Safety Instructions

Before using this product, it is necessary to consult this document to have a preliminary understanding and knowledge of the product, and to comply with the safety instructions in the product manual to ensure your personal safety and avoid damaging the equipment. If blind operation causes loss or injury, the manufacturer is not responsible for any problems related to the safety of the equipment and personal life and property caused by its incorrect operation

Personal Safety

- Before operating the equipment, wear anti-static work clothes, anti-static gloves or wristbands, and remove conductive objects such as jewelry and watches to avoid electric shock or burns.
- If a fire occurs, evacuate the building or equipment area and press the fire alarm bell, or call the fire alarm number. Under no circumstances should one re-enter a burning building.

Equipment Safety

- Before operation, the equipment should be reliably fixed on the floor or other stable objects, such as walls or mounting brackets.
- Do not block the air vent during system operation.
- When installing the panel, if the screws need to be tightened, tools must be used for operation.
- After installing the equipment, please clear the empty packaging materials in the equipment area.

- Supply Voltage

TW-T801 edge computing platform input power supply is stable and reliable, power 35W
Power Range: 9-19 V DC
Current: 5A (MAX)

- Environmental Requirements:

Woring Temperature： 0℃ -50℃
Ventilation Requirements: There must be good ventilation conditions around the installation of the computing platform

- Grounding Requirements

The power supply of the power adapter must have good grounding, and in special cases, grounding screws on the calculation platform must be installed for grounding
The following requirements only apply to equipment that requires grounding:

- When installing equipment, it must be grounded first; When dismantling the equipment, finally remove the grounding wire.
- It is prohibited to damage the grounding conductor.

- It is prohibited to operate the equipment without installing a grounding conductor.
- The equipment should be permanently connected to the protective ground. Before operating the equipment, the electrical connections of the equipment should be checked to ensure that it is reliably grounded.

- Electrostatic Protection

Electronic components and circuits are sensitive to electrostatic discharge. Although our company designs circuit board products with anti-static protection for the main interfaces on the board, it is difficult to achieve anti-static safety protection for all components and circuits. Therefore, it is recommended to follow anti-static safety protection measures when handling any circuit board components. Anti static safety protection measures include, but are not limited to, the following:

- During transportation and storage, the box should be placed in an anti-static bag until installation and deployment before removing the board
- Before touching the box, the static electricity stored inside the body should be discharged: wear a discharge grounding wristband
- Operate the box only within the safe area of the static discharge point
- Avoid moving boxes in carpeted areas.

- Basic Installation Requirements

The personnel responsible for installing and maintaining the equipment must undergo strict training, understand various safety precautions, and master the correct operating methods before installing, operating, and maintaining the equipment.

- Only qualified and trained personnel are allowed to install, operate, and maintain equipment.
- Only qualified professionals are allowed to dismantle safety facilities and repair equipment.
- Replacement and modification of equipment or components (including software) must be completed by personnel certified or authorized by the Twowin.
- Operators should promptly report any faults or errors that may cause safety issues to the responsible person.

# Introduction

TW-T801 is a computing platform designed based on NVIDIA® JETSON ORIN NX module, with built-in integrated ORIN Nx module and pre installed Ubuntu operating system. It has AI processing capability for 70/100 TOPS floating-point operations, a compact appearance, excellent heat dissipation, rich sensor interfaces, and outstanding performance, bringing new features to all your embedded AI and edge systems. It has the characteristics of strong computing power, high reliability, high integration, and low power consumption, and can be applied to commercial robots, medical instruments, intelligent cameras, high-resolution sensors, automatic optical inspection, smart factories, and other AIoT embedded systems..

TW-T801 Overview of Edge Computing Platform:

- Embedded NVIDIA® JETSON ORIN Nx
- Support M.2 KEY M (PCIEX4 NVME 2280)
- Supports multiple interfaces (such as CAN/US/Ethernet/serial/GPIO, etc.)
- Supports dual band WIFI 2.4G/5G
- Fan active cooling design
- Built in Ubuntu system and Jetpack SDKs
- Wide voltage 9-19V input

# Product Specification

## Processor and Core Module




| | | |
|---|---|---|
| Processor | NVIDIA Jetson Orin NX | |
| AI | 100 TOPS | 70 TOPS |
| CPU | 8-core Arm® Cortex®-A78AE v8.2 64-bit CPU<br>2MB L2 + 4MB L3 | 6-core Arm® Cortex®-A78AE v8.2 64-bit CPU<br>1.5MB L2 + 4MB L3 |
| CPU Max Frequency | 2GHz | |
| GPU | 1024-core NVIDIA Ampere architecture GPU with 32 Tensor Cores | |
| GPU Max Frequency | 918MHz | 765MHz |
| Memory | 16GB 128-bit LPDDR5 102.4GB/s | 8GB 128-bit LPDDR5 102.4GB/s |
| Storage | 1x M.2 Key M NVMe 2280 | |

## Interface Introduction

| | Interface | Quantity | Note |
|---|---|---|---|
| Network | Ethernet | 1 | 1*RJ45 Gigabit Independent Network Port |
| | WIFI | 1 | 2.4G/5.8G Optional installation |
| Video output | HDMI | 1 | HDMI 2.0 Compatible with 1.4 (output only) |
| USB | USB | 4 | USB 3.0 TYPE-A 5V@1A |
| | Type-C | 1 | USB2.0 Micro Brush machine use interface |
| 40Pin | GPIO,2xI2C,2xSPI,UART,I2S | / | /usr/share/doc/jetson-gpio-common/samples Official Routine |
| | 5V | 2 | 5V output |
| | 3.3 V | 2 | 3.3V output |
| 12Pin | Power,reset,recovery,UART console | / | The CAN pin defaults to no CAN transceiver,It needs to be accessed and used by oneself |
| User Expansion | M.2 | 1 | PCIE NVME 2280 SSD |

## Encoding and Decoding

| | |
|---|---|
| Video Encode | 1x 4K60 (H.265)<br>3x 4K30 (H.265)<br>6x 1080p60 (H.265)<br>12x 1080p30 (H.265) |
| Video Decode | 1x 8K30 (H.265)<br>2x 4K60 (H.265)<br>4x 4K30 (H.265)<br>9x 1080p60 (H.265)<br>18x 1080p30 (H.265) |

## Power Supply

| Power Supply | Spec |
|---|---|
| Input Type | 1xDC |
| Input Voltage | Wide input 9-19v |
| Typical consumption | 25W |

## Structure

| Mechanical | Spec |
|---|---|
| Dimensions (W×D×H) | 131mm×100mm ×52mm |

## Environment

| Environmental | Spec |
|---|---|
| Operating Temperature | 0℃-50℃ |

Size



# Service and Support

## Technical Support

If you encounter any problems or believe that your product has defects, please visit our official website with your questions and browse our common problem section to find solutions to common problems. You can also contact us by phone or WeChat, and we will make corresponding work arrangements according to your needs in a timely manner to solve your problems

## Warranty

Warranty period: The warranty period for our equipment is one year from the date of purchase.

Warranty Regulations: During the warranty period, if there is any non-human damage to the product, Twowin will provide free warranty. Please obtain warranty assistance through customer service dialogue and phone contact on the purchasing platform. (For details, please refer to the warranty regulations of Twowin Technology Co., Ltd.

# Interface Description

## Front Interface




Front interface diagram

| Interface Name | Quantity | Description |
|---|---|---|
| DC | 1 | DC power supply port supports wide voltage input of 9-19V |
| HDMI | 1 | HDMI 2.0 video output port (not available as input) |
| USB | 4 | USB 3.0 (connected to 1 HUB chip from the internal core to 4 USB3.0 ports, sharing 5G bandwidth) 5V-1A |
| LAN | 1 | RJ45 Gigabit Ethernet port (normal status: orange constantly on, green flashing) |
| TYPE-C | 1 | The USB 2.0 interface has the functions of external power supply and data transmission, with the most important function being the USB brush port IP：192.168.55.1 |

## WiFi antenna connection diagram

## Side Interface

## 40 PIN Show Picture



| PIN/BOARD NUM | BCM NUM | GPIO NUM | GPIO NAME | PIN/BOARD NUM | BCM NUM | GPIO NUM | GPIO NAME |
|---|---|---|---|---|---|---|---|
| 7 | 4 | 492 | PAC.06 | 11 | 17 | 460 | PR.04 |
| 12 | 18 | 398 | PH.07 | 13 | 27 | 470 | PY.00 |
| 15 | 22 | 433 | PN.01 | 16 | 23 | 474 | PY.04 |
| 18 | 24 | 473 | PY.03 | 19 | 10 | 483 | PZ.05 |
| 21 | 9 | 482 | PZ.04 | 22 | 25 | 471 | PY.01 |
| 23 | 11 | 481 | PZ.03 | 24 | 8 | 484 | PZ.06 |
| 26 | 7 | 485 | PZ.07 | 29 | 5 | 453 | PQ.05 |
| 31 | 6 | 454 | PQ.06 | 32 | 12 | 389 | PG.06 |
| 33 | 13 | 391 | PH.00 | 35 | 19 | 401 | PI.02 |
| 36 | 16 | 461 | PR.05 | 37 | 26 | 472 | PY.02 |
| 38 | 20 | 400 | PI.01 | 40 | 21 | 399 | PI.00 |

Note:

❶ The 8&10 pins are the only UART (TTL signal) serial ports that can be used for data transmission on this device, with the serial device number "/dev/ttyTHS1"

❷ Most of the pins in the 40 PIN have multiplexing function, and their default state is GPIO. If you need to modify their default state, please refer to the following link for introduction:
https://docs.nvidia.com/jetson/archives/r36.3/DeveloperGuide/HR/ConfiguringTheJetsonExpansionHeaders.html

❸ GPIO Terminal Command Method Description: (The following () content is a note explanation)

#Enter root account:
sudo -s(Press enter and enter password "nvidia")
#Enter the GPIO number to be used into the/sys/class/gpio/export file (using pin 492 as an example)
echo 492（492 为 GPIO NUM） > /sys/class/gpio/export
#Enter the corresponding GPIO file
cd /sys/class/gpio/PAC.06 (PAC.06 为 GPIO NAME)
#Granting execution authority
chmod 777 value
#Granting execution authority
chmod 777 direction
#Set as input state
echo in > direction
#Set as output state
echo out > direction
#Set to output high level
echo 1 > value
#Set to output low level
echo 0 > value

❹ Application examples

Example of using Python to call GPIO
/usr/share/doc/jetson-gpio-commmon/samples (native path)
Example of using C++to call GPIO
https://github.com/pjueon/JetsonGPIO/tree/master(Example of github)

## Back Interface




.

| | | |
|---|---|---|
| 1 | PWR BTN | Matched with DIS AUTO ON to achieve power on/off control |
| 2 | GND | |
| 3 | FC REC | Matched with GND to enter brush machine mode |
| 4 | GND | |
| 5 | SYS RST | Restart |
| 6 | GND | |
| 7 | DIS AUTO ON | Short circuit can prevent power on and self start, and can be used with PWR BTN and GND to control power on and off |
| 8 | DIS AUTO ON | |
| 9 | ART TXD | debug interface |
| 10 | ART RXD | |
| 11 | LED + | LED positive pole |
| 12 | LED - | LED nagative pole |
| 13 | 3.3V | 3.3V output |
| 14 | GND | |
| 15 | CAN RX | CAN communication, without resistors or transceivers, if used, requires external connection by oneself |
| 16 | CAN TX | |

# Usage Introduction

## System Introduction

The T801 device uses the Ubuntu system

Default Username: nvidia Password: nvidia

Our company has not set root username and password. If you need to enter the root user, please execute the following command: sudo -s

Enter password: nvidia

## Switch on and off

Power supply: Connect the device to the DC interface for power supply, and start the device when turned on.

Switch on: The default power on mode of TW-T201 device is self starting when powered on. Insert the power supply and connect the monitor to the device via HDMI interface. The graphical desktop is shown in the figure below:

Shutdown: The system performs a shutdown internally

Attention: Do not directly unplug the main power supply for shutdown operation, as this operation may cause damage to the disk




Startup Desktop

# Work Mode Switching

Different working modes, the use of cpu core and power is different, you can choose according to their own needs, click on the arrow to point to the option for mode selection




Command switching

sudo nvpmodel -m 0

#Among them, 0 is optiona

sudo jetson_clocks

#Set the fixed CPU frequency to the maximum frequency supported by the current mode, and restart will fail.

# WIFI Connection (if optional)

Wifi：There are various ways to connect to WiFi, including using the nmcli tool on the graphical interface and the terminal command line:

1、Graphical interface to connect to wifi

Click on the network icon

Select the wifi you want to connect to and enter the password



2、Terminal command to connect to WiFi

The terminal inputs the nmcli device wifi list to list the available WiFi connections:




Connect WiFi

Terminal input sudo nmcli device wifi connect MyWiFiSSID password MySecretPassword




At this point, you can use the WiFi network

Configure WiFi as a hotspot

iw list | grep -i dbm | grep -v no #View the currently available channel




Create hotspots using the nmcli tool:

sudo nmcli device wifi hotspot ifname wlan0 con-name Hotspot ssid TW_Hotspot password 12345678 band bg channel 1

sudo nmcli connection modify Hotspot connection.autoconnect yes

sudo nmcli connection modify Hotspot connection.autoconnect-retries 0




## Development environment configuration (the following operations are not mandatory, please follow personal needs for corresponding operations)

# 1 Update source and software

After installing the system, the source should be updated first, otherwise subsequent updates and upgrades will be very slow. However, as Jetson Orin Nx uses the aarch64 architecture Ubuntu 20.04.2 LTS system, which is different from AMD's Ubuntu system, it needs to be replaced with the aarch64 source. It is important to note not to replace it with the x86-64 source.

We have chosen Tsinghua's source for updating here. Firstly, backup the original source and change the name of the source.list file for future reference:

```
sudo cp /etc/apt/sources.list    /etc/apt/sources.list.bak
sudo vi /etc/apt/sources.list
```

Then delete all content, copy the following content and save it

```
deb https://mirror.tuna.tsinghua.edu.cn/ubuntu-ports/ focal main restricted universe multiverse
deb https://mirror.tuna.tsinghua.edu.cn/ubuntu-ports/ focal-updates main restricted universe multiverse
deb https://mirror.tuna.tsinghua.edu.cn/ubuntu-ports/ focal-backports main restricted universe multiverse
deb https://mirror.tuna.tsinghua.edu.cn/ubuntu-ports/ focal-security main restricted universe multiverse
deb https://mirror.tuna.tsinghua.edu.cn/ubuntu-ports/ focal-proposed main restricted universe multiverse
```

Open the terminal and enter the following command to update:

```
sudo apt-get update
```

The above update time is relatively long, and the update may fail due to network speed in the middle. At this time, do not shut down and re execute the command, as it will automatically resume from a breakpoint.

## 2 Set a fixed IP address with commands

Install netplan.io

sudo apt install netplan.io

Modify configuration file

sudo vi /etc/netplan/99_config.yaml

Add the following content

```
network:
  version: 2
  renderer: networkd
  ethernets:
    enp0s25:
      addresses:
        - 192.168.0.100/24(Set the static IP address according to your own needs here)
      routes:
        - to: default
          via: 192.168.0.1 (Fill in the IP segment)
      nameservers:
          search: [example.com, sales.example.com, dev.example.com]
          addresses: [1.1.1.1, 8.8.8.8, 4.4.4.4] (No need to change)
```

Restart the device to make the settings effective:

sudo reboot

# Basic Algorithm Framework Installation

## Pytorch Installation

Pytorch installation is closely related to the system version. Before installing different versions of Pytorch, first determine the jetpack version number of the device, and then use the following image to determine which version of Pytorch needs to be installed for normal use.

Based on Python 3.8 installation method (taking 1.8.0 as an example):

wget https://nvidia.box.com/shared/static/p57jwntv436lfrd78inwl7iml6p13fzh.whl -O torch-1.8.0-cp36-cp36m-linux_aarch64.whl
sudo apt-get install python3-pip libopenblas-base libopenmpi-dev
pip3 install Cython
pip3 install numpy torch-1.8.0-cp36-cp36m-linux_aarch64.whl

# Torchvision Installation

The installation of Torchvision is closely related to the pytorch version. Before installing Torchvision, it is necessary to check the pytorch version and determine which version of Torchvision needs to be installed based on the following image in order to use it properly

sudo apt-get install libjpeg-dev zlib1g-dev libpython3-dev libavcodec-dev libavformat-dev libswscale-dev

git clone --branch v0.x.0 https://github.com/pytorch/vision torchvision

cd torchvision

export BUILD_VERSION=0.x.0 # (Fill in the version number of torchvision installation)

python3 setup.py install

Verify
python3
>>> import torch
>>> print(torch.__version__)
>>> print('CUDA available: ' + str(torch.cuda.is_available()))
>>> print('cuDNN version: ' + str(torch.backends.cudnn.version()))
>>> a = torch.cuda.FloatTensor(2).zero_()
>>> print('Tensor a = ' + str(a))
>>> b = torch.randn(2).cuda()
>>> print('Tensor b = ' + str(b))
>>> c = a + b>>> print('Tensor c = ' + str(c))
>>> import torchvision
>>> print(torchvision.__version__)

Please refer to this page for the download address and detailed installation method of Pytorch whl package

# Yolo v4 environment setup

1.First download darknet on github

```
git clone https://github.com/AlexeyAB/darknet.git
```

2.After the download is complete, you need to modify the Makefile file

```
cd darknet
sudo vim Makefile
```

3.Change the first four rows from 0 to 1

```
GPU=1
CUDNN=1
CUDNN_HALF=1
OPENCV=1
```

4.The cuda version and path also need to be changed to our actual version and path, otherwise the compilation will fail

```
Change NVCC=nvcc to
NVCC=/usr/local/cuda-10.2/bin/nvcc
```

5.After the modification is completed, compile it and input it on the terminal

```
sudo make
```

6.Using YOLOv4 for reasoning

(1)There are three basic reasoning methods: images, videos, and cameras (real-time images)

(2)Choose Yolo v4 and Yolo v4 tiny (lighter models suitable for running on Jetson Orin Nano) for testing. Firstly, it is necessary to download the weight file of the trained model

Picture Test

```
./darknet detector test cfg/coco.data cfg/yolov4.cfg yolov4.weights data/dog.jpg
```

If you want to activate the image, you need to use test mode, which will ask you to input the position of the image after execution

```
./darknet detector test ./cfg/coco.data ./cfg/yolov4.cfg ./yolov4.weights
```

Video Test

Yolov4-tiny video detection (the video file is not included in the data downloaded from github, users need to upload the video file to be detected to the data folder by themselves)

```
./darknet detector demo cfg/coco.data cfg/yolov4-tiny.cfg yolov4-tiny.weights data/xxx.mp4
```




Download link for development materials

Link: https://pan.baidu.com/s/1iMEFFJu9sjLpXn6Xq1ozzw?pwd=mmkc

# TWOWIN Information Technology(ShenZhen)Co.,Ltd. Warranty Terms

Important Note

Twowin Information Technology (Shenzhen) Co., Ltd guarantees that each embedded product provided has no defects in materials and processes to the best of our knowledge, and fully complies with the specifications officially shipped from the original factory.

Twowin Information Technology (Shenzhen) Co., Ltd warranty coverage includes all original products. If the accessories configured by the dealer malfunction, please consult with the dealer to resolve it. The warranty period for all products provided by the technology is one year (lifetime repair service is provided for products beyond the warranty period), and the warranty period starts from the date of manufacture. For products repaired during the warranty period, the warranty for the repaired part is extended by 12 months. Unless otherwise notified by Technology, the date on your original shipping order is the factory date

How to obtain warranty service

If the product cannot operate normally during the warranty period, please contact Twowin Information Technology (Shenzhen) Co., Ltd or the dealer to obtain warranty service. When the product is under warranty, please present the purchase invoice as proof of your right to receive warranty service.

Warranty Solution Measures

When you request warranty service, you need to follow the problem determination and resolution procedures outlined in the technology regulations. You need to receive the first diagnosis from our technical personnel via phone or email. At that time, you will need to cooperate and fill in all the issues on the repair form we provide in detail to ensure that we accurately determine the cause of the fault and the location of the damage (we will also provide a fee list for products that are out of warranty and require your confirmation). The technology has the right to "repair" or "replace" the reported product. If the product is "replaced" or "repaired", the replaced "faulty" product or the repaired "faulty" part will be returned to the technology. Due to the need to send some repaired products to the original factory, in order to avoid accidental losses, the picture shows Technology requesting that you purchase transportation insurance. If the user abandons the insurance, the shipped items will be damaged or lost during transportation, and Technology will not be held responsible. For products within the warranty period, the user is responsible for the shipping cost when the repaired product is returned to the manufacturer. The picture shows that Technology is responsible for the shipping cost of returning the repaired product to the user.

The following situations are not covered by the warranty:

1、 Inappropriate installation, improper use, misuse, and abuse of products (such as exceeding work load, etc.)

2、 Product failure or damage caused by improper maintenance and storage (such as fire, explosion, etc.) or natural disasters (such as lightning, earthquake, typhoon, etc.)

3、 Changes to the product (such as circuit characteristics, mechanical characteristics, software characteristics, three proof treatment, etc.)

4、 Other faults that are clearly caused by improper use (such as high voltage, low voltage, high floating voltage, reversed polarity, bent or broken pins, wrong bus connection, device detachment, electrostatic breakdown, external compression, falling under impact, high temperature, high humidity, poor transportation, etc.)

5、 Markings and part numbers on the product have been redacted or removed.

6、 Product out of warranty

Special Note:

If multiple products experience the same malfunction or multiple occurrences of the same malfunction or damage on the same device, it is necessary to identify the cause and confirm responsibility. Our company has the right to request users to provide physical or technical information on peripheral devices, such as monitors, I/O

devices, cables, power supplies, connection diagrams, system architecture diagrams, etc. Otherwise, we have the right to refuse to fulfill the warranty, and repair fees will be charged at market prices and a repair deposit will be collected.